



# Quick Start Guide



Note: For complete information about using all of your JBL Bar 5.1, download the full Owner's Manual from [www.jbl.com](http://www.jbl.com).

### 1 What's in the box

Soundbar Main Unit

Subwoofer

Remote Control

Wireless Surround Speakers

Power Cables\* (4ft, 1200mm)

HDMI Cable (6.6ft, 2000mm)

AUX cable (4ft, 1200mm)

Optical Cable (4ft, 1200mm)

Calibration Microphone

Wall-Mount Brackets

Product Information & Wall-mounted guide

### 2 Place your soundbar

#### 2a. Place the soundbar on the table

#### 2b. Wall mount the soundbar

Use tape to stick the wall-mounted paper guide on the wall, push a pen tip through the center to mark the wall-mounted bracket location and remove the paper.

#### 2c. Dock the wireless speakers

Wireless speakers charge during soundbar standby mode.

### 3 Connect your soundbar

#### 3a. Connect to your TV

#### 3b. Connect to other devices

### 4 Power your system

### 5 Control your soundbar

#### 5a. Top Panel

### 5b. Remote control

- Power
- Source\*
- Play / Pause
- Volume -
- Volume +
- Previous
- Next
- Wireless Surround Level+
- Wireless Surround Level-
- Mute
- Bass +
- Bass -
- Sound mode\*\*
- Shuffle / Repeat
- Calibrate Audio
- Night mode On / off
- Dim display
- Bluetooth
- Audio Sync +
- Audio Sync -

\*Switch between HDMI ARC / HDMI 1 / HDMI 2 / HDMI 3 / Optical / AUX / Bluetooth / USB  
 \*\*Switch between Standard / music / movie / voice / sports sound mode or press and hold 5 seconds to reset default audio setting

### 6 Bluetooth® connection

#### 6a. Press Remote Control Bluetooth button to enter Bluetooth source

#### 6b.

Bluetooth Settings: JBL Bar 5.1 Connected

#### 6b.

Remark: Press and hold Remote control Bluetooth button for 3 seconds if you want to pair another mobile device

### 7c.

### 7d.

Press Soundshift button to enable Soundshift feature.

### 9 Respond to Your TV Remote Control

Use your own TV remote control to control your soundbar

#### 9a. For most Samsung, LG, Sony and Vizio TVs

The soundbar responds to your TV remote control automatically. Press and hold soundbar remote control SHUFFLE button if you want to disable this function.

#### 9b. For other TVs

Please manually program the soundbar to respond to your TV remote control step by step. First, press and hold VOLUME+ and SOURCE to enter learning mode.

### 10 Product Specifications

Total Power	218WRMS
Soundbar Power	43.8WRMS
Subwoofer Power	164WRMS
Surround Speaker Power	2 x 5.4WRMS
Surround Speaker Play Time	10 hours
Battery charge time	< 3 hours
Soundbar Transducer Size	6 x 2.25" racetrack drivers 3 x 1.25" tweeter
Subwoofer Transducer Size	10"
Max SPL	104dB
Frequency Response	35Hz to 20KHz
Operating Temperature	0°C - 45°C
Audio Inputs	1 Analog, 1 Optical, Bluetooth, USB
HDMI Video Inputs	3
HDMI Video Output (with Audio Return Channel)	1
HDMI HDCP Version	2.2
Bluetooth Version	4.2
Bluetooth Profile	A2DP V1.3 / AVRCP V1.6
Bluetooth Frequency Range	2402MHz-2480MHz
Bluetooth Max Transmitting power	9dBm (EIRP)
Bluetooth Transmitter modulation	GFSK, π/4 QPSK, 8DPSK
5.8G Wireless Frequency Range	5725MHz- 5875MHz
5.8G Max Transmitting power	9dBm (EIRP)
Soundbar Dimensions (W x H x D)	1148 x 58 x 93 (mm) \ 45" x 2.3" x 3.7"
Soundbar Weight	3.9kg \ 8,6 lbs
Subwoofer Dimensions (W x H x D)	440 x 305 x 305 (mm) \ 16" x 12" x 12"
Subwoofer Weight	13kg \ 28.7 lbs
Surround Speaker Dimensions (W x H x D)	165 x 59 x 93 (mm) \ 6.5" x 2.3" x 3.7"
Surround Speaker Weight	0.6kg \ 1,3 lbs
Packaging Dimensions (W x H x D)	1008 x 379 x 455 (mm) \ 39.7" x 14.9" x 17.9"
Packaging Weight (Gross)	20.95kg \ 46.1 lbs

### 9a. For most Samsung, LG, Sony and Vizio TVs

The soundbar responds to your TV remote control automatically. Press and hold soundbar remote control SHUFFLE button if you want to disable this function.

### 9b. For other TVs

Please manually program the soundbar to respond to your TV remote control step by step. First, press and hold VOLUME+ and SOURCE to enter learning mode.

### 10 Product Specifications

Total Power	218 WRMS
Soundbar Power	43.8 WRMS
Subwoofer Power	164 WRMS
Surround Speaker Power	2 x 5.4 WRMS
Surround Speaker Play Time	10 hours
Battery charge time	< 3 hours
Soundbar Transducer Size	6 x 2.25" racetrack drivers 3 x 1.25" tweeter
Subwoofer Transducer Size	10"
Max SPL	104dB
Frequency Response	35Hz to 20KHz
Operating Temperature	0°C - 45°C
Audio Inputs	1 Analog, 1 Optical, Bluetooth, USB
HDMI Video Inputs	3
HDMI Video Output (with Audio Return Channel)	1
HDMI HDCP Version	2.2
Bluetooth Version	4.2
Bluetooth Profile	A2DP V1.3 / AVRCP V1.6
Bluetooth Frequency Range	2402MHz-2480MHz
Bluetooth Max Transmitting power	9dBm (EIRP)
Bluetooth Transmitter modulation	GFSK, π/4 QPSK, 8DPSK
5.8G Wireless Frequency Range	5725MHz- 5875MHz
5.8G Max Transmitting power	9dBm (EIRP)
Soundbar Dimensions (W x H x D)	1148 x 58 x 93 (mm) \ 45" x 2.3" x 3.7"
Soundbar Weight	3.9kg \ 8,6 lbs
Subwoofer Dimensions (W x H x D)	440 x 305 x 305 (mm) \ 16" x 12" x 12"
Subwoofer Weight	13kg \ 28.7 lbs
Surround Speaker Dimensions (W x H x D)	165 x 59 x 93 (mm) \ 6.5" x 2.3" x 3.7"
Surround Speaker Weight	0.6kg \ 1,3 lbs
Packaging Dimensions (W x H x D)	1008 x 379 x 455 (mm) \ 39.7" x 14.9" x 17.9"
Packaging Weight (Gross)	20.95kg \ 46.1 lbs